



	OPEN/CLOSE	OPEN/OUTSW	CLOSE	INSW	LOADER MOTOR
OPEN	1	0	0	1	Rev Turning Stop
CLOSE	0	0	1	1	Fwd Turning Stop



